

Ford Explorer & Mercury Mountaineer ECU Removal Instructions

The computer box is located on the firewall, passenger side/center (see image).

1. Make sure the key is NOT in the ignition!!!
2. Remove the negative terminal from the battery.
3. Remove the 10mm bolt from the center of the computer box.
4. Unplug the wiring harness from the box.
5. Remove the nut holding down each side of the computer box.
6. Slide the computer out.
7. Installation is the reverse of these steps.

