

Pontiac Aztek, Buick Rendezvous 2001-2005 ABS MODULE REMOVAL

1. Turn the ignition switch to the **OFF** position.
2. Remove the air cleaner housing from the engine compartment.
3. Disconnect the Electronic Brake Control Module (EBCM) harness connector.
4. Brush off any dirt/debris that has accumulated on the assembly.
5. Disconnect the pump motor connector at the bottom of the EBCM.
6. Do not damage the seal by prying the EBCM from the brake pressure modulator valve (BPMV).
7. Do not damage the solenoid valves while removing the EBCM from the BPMV.
8. Remove the six EBCM to BPMV screws.
9. Separate the EBCM from the BPMV by gently pulling apart until separated.

