

## 1998-2002 Mercedes ML320 ABS Assembly Removal

The ML320 uses separate modules for the solenoid valves and the ABS controller. The module attached to the hydraulic unit only contains solenoids.

The solenoid pack is attached to the hydraulic unit located near the front left (driver's) side of the engine compartment (see red arrow). You will need to send the entire assembly for repair.

1. **Disconnect the negative battery cable.**
2. **Bleed off the brake fluid by attaching a hose to the bleeder valve on both a front and rear caliper.**
3. **Keep the brake pedal depressed using a brake pedal depressor.**
4. **Detach the brake lines attached to the HCU and label as shown (see next page).**
5. **Disconnect the electrical connector**
6. **Remove the ECU mounting bolts.**
7. **Remove the HCU.**

