

!!!ATTENTION!!!

There are 2 metal contact prongs connecting the VSA modulator (ABS module) to the hydraulic pump. Sometimes those contacts will come out on the module side during removal. **THE CONTACT PRONGS MUST BE INSTALLED ON THE PUMP SIDE BEFORE RECONNECTING THE MODULE.** If you do not install the module properly, the contacts will bend and touch each other, creating an electrical short that will destroy the VSA modulator. If your module is destroyed as a result of not following these instructions, your warranty will be voided. Please be advised.

Correct



Incorrect

