

# Toyota Tundra & Tacoma ABS Module Removal Instructions

The ABS module is located in the rear passenger side corner of the engine compartment. Start by removing the nuts securing the hydraulic pump bracket to the vehicle. This will give you enough room to maneuver the assembly so that you will be able to remove the module from the hydraulic pump. Remove the 4 reverse torx bolts securing the ABS module to the pump. You will have to slightly bend the brake lines in order to do this. Then disconnect the wiring harness and slide the module off of the pump.

